

STEINFURTH BOTTLE PRESSURE TESTER

...Ergonomic manual pressure measurement in packages



The Steinfurth Bottle Pressure Tester is easily ergonomic attached to glass bottles with crown closures or PET bottles. It pierces the closure, and the internal pressure can be read from the digital or analogue pressure gauge.

BENEFITS:

- Direct readings of the internal pressure
- Digital or analogue pressure gauge
- Easy operation (single-handed)
- Exchangeable adapters for many bottle types

OPERATION:

The Bottle Piercing Device is equipped with an adapter, which is slipped underneath the crown closure or the PET neck ring. At the same time, it aligns the device on the closure. By single-handed operation of a handle, the device is clamped onto the closure. By this, the closure is pierced by a hollow needle.

The internal pressure can be read from the pressure gauge. The Bottle Piercing Device is available with an analogue as well as with a digital pressure gauge.

TECHNICAL DATA:

Pressure range: 0...6 bar / 0...87 PSI (analogue)
0...8 bar / 0...116 PSI (digital)

Pressure accuracy: 1% FS (analogue)
0.1% FS (digital)



PET bottle



Crown closure

Архангельск (8182)63-90-72
Астана +7(7172)727-132
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Казань (843)206-01-48

Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41

Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: shf@nt-rt.ru || www.steinfurth.nt-rt.ru