

FOAM STABILITY TESTER

...for perfect automatic foam stability testing

Foam stability is an important beer quality parameter. Measuring foam stability, however, has been so far either laborious or inaccurate – or both.

The demand for an accurate and user-/location-independent stability measurement device led to the development of the automatic Steinfurth Foam Stability Tester.



BENEFITS:

- Good reproducibility
- Results comparable to Ross & Clark
- Automatic sampling
- Automatic rinse
- Simple operation
- User independent
- Constant absolute pressure – location / ambient pressure independent measuring (optional)
- Suitable for all beer sorts
- Optoelectronic detection
- Precise dosing
- Simple cleaning

OPERATION:

The container (bottle or can) with the beer to be measured is connected to the Steinfurth Foam Stability Tester, using a sampling device. The beer is moved into the FST by CO₂ pressure. The pressure is such that the beer doesn't degasify inside the container.

The beer is ejected into the glass cylinder through a nozzle, converting it into foam. Foam stability is calculated from the timing of the passing of the beer / foam boundary along some optical sensors.

Before every measuring, the cylinder is rinsed automatically. It is possible to start an automatic series of several consecutive and independent measurements from the same container.

TECHNICAL DATA:

Container type:	Bottle or can
Duration of 1 measuring:	approx. 5 minutes
Data output:	LC display 2 lines with 20 characters
Interface:	RS 232 (PC or printer)
Power supply:	230/115VAC
Rinse fluid:	Tap water
CO ₂ supply pressure:	4.5 bars (65psi)

Архангельск (8182)63-90-72
Астана +7(7172)727-132
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89
Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Казань (843)206-01-48

Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81
Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41

Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78

Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

Единый адрес для всех регионов: shf@nt-rt.ru || www.steinfurth.nt-rt.ru